




TETRIX  
portable displays

# Alu Lite Totem



- **Deliver full template size**
- **Resolution 75-150 dpi**
- **Only JPG (JPEG) format**
- **No bleed**
- **No pre-press marks**
- **Only CMYK colors**

(Visible 52x190, 70x190, 94x190)  
(in full 1:1 size)  
(We only accept jpg format, full size layouts)  
(Strict full size only)  
(crop marks, scales...)  
(not RGB or Pantone)

## **CHECK before uploading:**

That layout measurements are correct to fit the system  
That the colors are vivid enough to appear (over 30% CMYK)  
That the resolution and picture quality are OK


## **NOTE:**

TETRIX considers uploaded documents to fulfill requirements in accordance to these notes. No separate layout check is performed.



TETRIX  
portable displays

# Alu Lite Totem SKY



- **Deliver full template size**
- **Resolution 75-150 dpi**
- **Only JPG (JPEG) format**
- **No bleed**
- **No pre-press marks**
- **Only CMYK colors**

(Visible 94x240, 144x240)  
(in full 1:1 size)  
(We only accept jpg format, full size layouts)  
(Strict full size only)  
(crop marks, scales...)  
(not RGB or Pantone)

#### **CHECK before uploading:**

That layout measurements are correct to fit the system  
That the colors are vivid enough to appear (over 30% CMYK)  
That the resolution and picture quality are OK


#### **NOTE:**

TETRIX considers uploaded documents to fulfill requirements in accordance to these notes. No separate layout check is performed.




TETRIX  
portable displays

# Alu Lite Totem





- a) Connect the octagonal rods two-by-two, using the supplied threaded joints.
- b) Should the grooves in the rods not align, simply loosen one rod half a turn and tighten the other rod.
- c) Attach the foot through hole number 1 with the M10 bolt. Hole number 2 can be used when there is limited space behind the Alu Lite Totem.
- d) Attach the end caps

Insert the keder of the printed canvas into the grooves in the beams.



Attach the beams to the rods using the torx key.

- Put the end of the rail in to the groove of the rod and lock in place by turning the screw 180 degrees clockwise. To open, turn counter clockwise.
- Tip: Build the first module with it laid down on the floor and lift it up on to its feet after assembly.



Extra









- 1) Threaded pin for holding cell board signs
- 2) Spotlight
- 3) Cookie table



TETRIX  
portable displays

# Alu Lite Totem

## parts list









		Amount	Checked
	Octagonal rod		<input type="checkbox"/>
	Beam		<input type="checkbox"/>
	Lock		<input type="checkbox"/>
	end cap		<input type="checkbox"/>
	M10 bolt		<input type="checkbox"/>
	M10 threaded joint		<input type="checkbox"/>
	allen key		<input type="checkbox"/>
	torx key		<input type="checkbox"/>
	print		<input type="checkbox"/>
			<input type="checkbox"/>



TETRIX  
portable displays

# Alu Lite Totem

## optional items

		Amount	Checked
	spotlight		<input type="checkbox"/>
	lite spotlight		<input type="checkbox"/>
	spot light holder		<input type="checkbox"/>
	sign holder		<input type="checkbox"/>
	brochure holder		<input type="checkbox"/>
	cookie table		<input type="checkbox"/>
	slim foot		<input type="checkbox"/>
	round foot		<input type="checkbox"/>

Date

Signature